

1. Place the game in the Game Copier. The copier will automatically copy the game.

2. Press the copy button. The copier will copy the game.

3. Press the stop button. The copier will stop copying the game.

4. Pick up the copy. The copy is now ready to be used.

5. Repeat the process for each game you wish to copy.

### IMPORTANT

# GAME COPIER

Read the instructions carefully.

### Instructions for use

1. Connect the power cord to your Atari 1301 game console and the Game Copier. Then connect the power cord with the power supply.
2. Insert the game cassette which is to be copied into the left slot of the Game Copier.
3. Press the copy button. The copier will copy the game into the right slot of the Game Copier.
4. Press the stop button. The copier will stop copying the game.
5. Pick up the copy. The copy is now ready to be used.

### IMPORTANT

The Game Copier will not copy any game which is not in the Atari 1301 format. The Game Copier will not copy any game which is not in the Atari 1301 format.

**Gebruiksaanwijzing:**

1. Sluit uw Atari (TM) voedingseenheid aan op de GAME COPIER.  
Sluit vervolgens de voedingseenheid aan op de netspanning.
2. Plaats de te kopiëren spelcassette in de linker aansluiting van de GAME COPIER.
3. Plaats een lege (!) copier cassette in de rechter aansluiting van de GAME COPIER.
4. Druk op de rode startknop tot het rode lampje op de GAME COPIER gaat branden.
5. Wacht tot het rode lampje vanzelf uitgaat en verwijder dan de beide cassettes, de copier cassette is nu gereed voor gebruik in uw Atari (TM) spelcomputer.

**BELANGRIJK:**

Plaats of verwijder geen cassettes zolang het rode lampje brandt, dit kan uw copier cassette beschadigen!

Atari is een handelsmerk van Atari-Inc.

**Instructions for use:**

1. Connect the power unit of your Atari (TM) game computer with the GAME COPYER.  
Then connect the power unit with the mains voltage.
2. Insert the game cassette which is to be copied into the left slot of the GAME COPYER.
3. Insert an empty (!) copier cassette into the right slot of the GAME COPYER.
4. Press the red start button until the red light goes on.
5. Wait until this light goes out by itself again. Now remove the cassettes. The copier cassette is now ready for use in your Atari (TM) game computer.

**IMPORTANT:**

Do not insert or remove any cassette as long as the red light on the GAME COPYER is on, this may irreparably damage your copier cassette.

Atari is a trade mark of Atari-Inc.

Videospelen welke met behulp van de GAME COPYER kunnen worden gedupliceerd:

Videogames which can be duplicated with the help of the GAME COPYER:

Atari:

Combat	Sky Diver	Casino
Space War	Circus Atari	Yar's Revenge
Slot Racers	Superman	Fun with Numbers
Super Breakout	Space Invaders	Hangman
Warlords	Night Diver	Volleyball
Defender	Golf	Miniature Golf
Adventure	Maze Craze	Slot Machine
Pele's soccer	Video Checkers	Air Sea Battle
Backgammon	Dodge 'em	Basketball
3-D tic tac toe	Missile Command	Surround
Video Olympics	Video Pinball	Blackjack
Human Cannonball	Berzerk	

Activision:

Skiing	Pitfall	Grand Prix
Bridge	River raid	Dragster
Tennis	Spider fighter	Boxing
Freeway	Seaquest	Laser Blast
Kaboom	Oink	Fishing Derby
Stampede	Keystone Kapers	Sky jinks
Ice Hockey	Enduro	Dolphin
Chopper Command	Plague Attack	
Starmaster	Pressure Cooker	
Megamania	Barnstorming	

Parker brothers:

Frogger	Popeye	Ronald McDonald
Spidorman	Tutankamon	Strawberry Shortcake
Super Cobra	Action Force	The Incredible Hulk
Jedi Arena	Amidar	The empire strikes back
Ewok Adventure	Sky skipper	James Bond, octopussy
Death Star battle	Q-bert	
Reactor	Lord of the rings	

Imagic:

Demon Attack	Dragonfire	Riddle of the Sphinx
Star Voyager	No Escape	Hop to it
Trick Shot	Fathom	Quick step
Cosmic Ark	Solar Storm	Laser Gates
Firefighter	Moonsweeper	Wing war
Atlantis	Tarantula	Subterranea

Spectravision:

Planet Patrol	China syndrome	Sector Alpha
Tape Worm	Master Builder	Time Escape
Nexar	Galactic Tactic	Gold mine
Gangster alley	Mangia	Vortex

**Coloco:**

Donkey Kong  
 Mouse Trap  
 Carnival  
 Wizard of Wor  
 Golf  
 Venture  
 Zaxxon

Lady Bug  
 Turbo  
 Stomp it  
 Tunnel Runner  
 Wings  
 Blue print  
 Smurf Rescue at Gargamel's Castle

Kickman  
 Mountain king  
 Omega race  
 Solar Fox  
 Tang

**20th Century Fox:**

Bank Heist  
 Fantastic Voyage  
 Worm War 1  
 Boony Bopper  
 Alien  
 Fast Eddie  
 Turmoil  
 Deadly Duck  
 Crypts of Chaos  
 Fall Guy  
 Alligator People

9 to 5  
 Mega Force  
 Mesh  
 Flash Gordon  
 Porky's  
 Space Master X-7  
 Revenge of the Beefsteak Tomatoes  
 Voyage to the bottom of the sea  
 Butch Cassidy and the Sundance Kid  
 The earth dies screaming

**Tigervision:**

King Kong  
 Threshold  
 Jawbreaker  
 Scraper Caper

Murderer  
 Miner 2049er  
 Intuition  
 Mr. Cool

Polaris  
 Springer

**Commaid:**

Room of Doom  
 Cakewalk

Cosmic Swarm  
 Rush Hour

Mines of Minoas  
 Stronghold

**Home vision:**

Robot Attack

Sky Alien

Parashute

**Dimax:**

Space Robot

Astro War

**Bomb:**

Assault  
 Z-teck

Great Escape  
 Splendour

Wall Defender

**Games:**

X-Man

Deze lijst is gecontroleerd en wordt verondersteld betrouwbaar te zijn, C.S.K. kan echter niet aansprakelijk worden gesteld voor de gevolgen van fouten of gebreken in deze lijst.

This list has been carefully checked and is believed to be reliable, however, C.S.K. cannot be held responsible for inaccuracies that may not have been caught.